


Volkswagen MK5 Upper Bag Bracket Installation Instructions

IDF010

To Install the IDF upper bag bracket, a rivet nut must be installed inside of the rear spring perch. All necessary hardware is provided in the kit. Please use the following instructions as a guide.


- Drill the existing hole in the spring perch to 9/16" using a drill bit or step bit (figure 1)
 (**If your spring perch has already been cut or modified, a hole must be drilled into the frame
 of the car for the threaded insert. Longer hardware can be provided upon request to IDF**)
- 2. Prepare the rivet nut tool by threading the rivet nut onto the shorter side of the 3/8" threaded stud in the orientation shown in figure 2, until it is tight by hand, then back off an eighth of a turn.
- 3. Insert the external tooth washer onto the stud followed by the rivet nut tool. (figure 2)
- 4. Thread the 3/8" nut against the rivet nut tool, hand tight. (figure 3)
- 5. Insert the rivet nut into the drilled hole on the car so it is flush with the spring perch. (Figure 4)
- 6. Using a 9/16" ratchet and the rivet nut tool as a handle, tighten the nut while applying a steady upward pressure. Continue to tighten the nut until it becomes noticeably harder to turn, at this point tighten the nut ¾ of a turn to lock the rivet nut in place. If a torque wrench is available, apply 20 lb. ft. to the nut. (Figure 5)
- 7. Loosen and remove the nut, rivet nut tool, and external tooth washer, followed by the 3/8" stud using pliers.
- 8. Now the upper bag bracket can be installed, Orient the bracket with the air fitting cut out facing away from you, and bolt it in place using the countersunk 3/8" bolt. (figure 6)
- 9. Install the 90 degree air fitting into the bag using thread sealant.
- 10. With the bag mocked into place, check for clearance between the air fitting and the frame. If needed, the fitting may need adjusted to allow clearance.
- 11. Install the air bag using 2 of the 3/8" zinc plated flange head bolts and a 9/16" wrench.





Innovative Design & Fabrication LLC 6354 Lincoln Highway West Thomasville, PA 17364 717-779-7677 INNFAB.com Page **1** of **2**











Innovative Design & Fabrication LLC 6354 Lincoln Highway West Thomasville, PA 17364 717-779-7677 INNFAB.com Page **2** of **2**