





**Application Part Number:** SL00434 (Front Kit)



**Developed On:** 2015 BMW 335i Sedan RWD



**Recommended Ride Pressure:** 55 PSI

(Do not exceed 200 PSI)



**Recommended Damping:** 16 Clicks

(Clockwise clicks from full soft)



**Recommended Thread Length:** 46 mm

(Measurement between lockrings)



**Developed On:** 2012 BMW 318d Wagon AWD



**Recommended Ride Pressure:** 50 PSI

(Do not exceed 200 PSI)



**Recommended Damping:** 16 Clicks

(Clockwise clicks from full soft)



**Recommended Thread Length:** 55 mm

(Measurement between lockrings)










## **Installation Notes:**



**NOTE:** The recommendations and notes in this document were derived from the research and road testing conducted by Bag Riders using the vehicle listed above. If you are installing part(s) on a different vehicle, please ensure that air spring clearances are checked throughout the entire suspension travel range, including fully collapsed (aired out). In regards to damping and pressure recommendations: these are what we preferred for ourselves. We encourage you to experiment and find your most ideal suspension feel on your personal vehicle. Use our recommendations as a starting point!





