



**Application Part Number:** SL00371 (Front Kit)



**Developed On:** 2008 BMW M3 RWD



**Recommended Ride Pressure:** 50 PSI  
*(Do not exceed 200 PSI)*



**Recommended Damping:** 15 Clicks  
*(Clockwise clicks from full soft)*



**Recommended Thread Length:** 9 mm  
*(Measurement between lockrings)*

### Installation Notes:

N/A

**NOTE:** The recommendations and notes in this document were derived from the research and road testing conducted by Bag Riders using the vehicle listed above. If you are installing part(s) on a different vehicle, please ensure that air spring clearances are checked throughout the entire suspension travel range, including fully collapsed (aired out). In regards to damping and pressure recommendations: these are what we preferred for ourselves. We encourage you to experiment and find your most ideal suspension feel on your personal vehicle. Use our recommendations as a starting point!