

(Clockwise clicks from full soft) **Recommended Thread Length:** (Measurement between lockrings) 95 mm

## **Installation Notes:**

May need to cut fender pinch welds and install other aftermarket suspension arms to go lower.

**NOTE:** The recommendations and notes in this document were derived from the research and road testing conducted by Bag Riders using the vehicle listed above. If you are installing part(s) on a different vehicle, please ensure that air spring clearances are checked throughout the entire suspension travel range, including fully collapsed (aired out). In regards to damping and pressure recommendations: these are what we preferred for ourselves. We encourage you to experiment and find your most ideal suspension feel on your personal vehicle. Use our recommendations as a starting point!







