



Application Part Number: SL00183 (Front Kit)



Developed On: 2007 Subaru WRX Wagon AWD



Recommended Ride Pressure: 50 PSI
(Do not exceed 200 PSI)



Recommended Damping: 14 Clicks
(Clockwise clicks from full soft)



Recommended Thread Length: 41 mm
(Measurement between lockrings)

Installation Notes:

Please check for protruding mounting nuts or studs on the inner strut tower and remove them before install.

NOTE: The recommendations and notes in this document were derived from the research and road testing conducted by Bag Riders using the vehicle listed above. If you are installing part(s) on a different vehicle, please ensure that air spring clearances are checked throughout the entire suspension travel range, including fully collapsed (aired out). In regards to damping and pressure recommendations: these are what we preferred for ourselves. We encourage you to experiment and find your most ideal suspension feel on your personal vehicle. Use our recommendations as a starting point!



bagriders.com



superlow.com



sales@bagriders.com



(844) 404-7344